


CORnell®

User Manual



Tower Fan


CTF-P53D

General Safety Precautions


1. Thank you for your purchase of this appliance. Read all instructions carefully. Keep this User Manual for future reference.
2. Always switch off and unplug the appliance from the electrical outlet **BEFORE** cleaning and also when not in use.
3. Never immerse the appliance, power cord or plug into water or other liquids. Please refer to the section on "Care and Cleaning".
4. If it is a detachable power cord, always connect the power cord to the appliance first **BEFORE** plugging it into the electrical outlet. To disconnect the appliance, switch off the power on the electrical outlet before removing the power plug.
5. Close supervision is necessary when operating the appliance near children. Ensure that the power cord does not hang over the work surface.
6. Do not operate the appliance with a damaged power cord set or plug. Any repairs should always be carried out by an authorized service centre.
7. Do not use the appliance for any purposes other than its intended use. This appliance is intended for household use only.
8. Do not use the appliance in the outdoors or in a damp area.
9. Do not place the appliance on or near a hot gas or electric burner, or near easily flammable materials.
10. This appliance should not be used by people who are physically or mentally impaired (including children) unless proper guidance is provided during operation.

Parts Identification


Front View




Back View



1. Control Panel Cover
2. Control Panel
3. LCD Display Panel
4. Remote Control Sensor
5. Wind Outlet
6. Base
7. Remote Control Sensor
8. Handle
9. Screw
10. Remote Control Holder
11. Dustproof Filter
12. Remote Control



Control Panel Display



Specifications

Model No.	CTF-P53D
Rated Voltage	220-240V~
Rated Power	40W
Frequency	50Hz

Operating Instructions

Assembling Method

1. Unpack the appliance from the gift box.
2. Lay the main body horizontally on the ground.
3. Assemble the front base and rear base.
4. Insert the assembled base to the main body. Use the base screws (provided) to secure base to the main body.
5. Lift the Tower Fan upright.
6. Do not use this appliance before finish assembling.



Fig. 1



Fig. 2




Fig. 3




Fig. 4

Operating Procedure

- The appliance is to be operated by selecting the function keys at the control panel or using the remote control provided.

ON/OFF Key

- Turn the fan ON by pressing ON/OFF key. The fan will automatically operate in low speed and the low speed indicator light will on.
- Press this key again to turn off the fan.

PLASMA / ION Key

- Press this key to turn on the plasma/ionizer function and press again to turn it off.

OSCL Key

- To activate the appliance with oscillation, press the OSCL key once. The fan will oscillate horizontally at 90 degrees and the corresponding angle will be displayed on LCD. The oscillation mode can be manually adjusted in sequence at 90 degrees, 180 degrees or 360 degrees.

First Press	Oscillates in 90 degrees
Second Press	Oscillates in 180 degrees
Third Press	Oscillates in 360 degrees
Fourth Press	Oscillation function is off


Timer Key

- Turn on the fan by pressing the ON/OFF key once.
- Press the TIMER key to set the desired time for the fan to operate. The TIMER indicator light will turn on while the LCD will display the remaining time. When the set time is reached, the fan will switch itself OFF automatically. Press the TIMER key continuously to set the time from 1 to 12 hours.

Mode Key

- Press this key for mode selection of either normal, natural or sleep mode.
- Normal Mode: The appliance will operate at selected fan speed of Low, Medium and High.

- **Wise Mode:** The appliance will operate according to the temperature automatically as shown on the chart below:



- **Natural Mode:** The appliance will operate in the sequence of high-mid-low speed, in a repeat manner automatically.
- **Sleep Mode:** The appliance will operate according to computerized intervals of changing speeds as follow:
 - High Sleep Mode Operates at high-mid-low natural wind, each for 30 minutes interval time, in a repeat manner automatically.
 - Medium Sleep Mode Operates at mid-low natural wind, each for 30 minutes interval time, in a repeat manner automatically.
 - Low Sleep Mode Operates at low natural wind.

“+” & “-” Key

- Press “+” or “-” to increase or decrease the wind speed respectively. The wind speed can be set from the range of 1 to 8 speed level.
- The appliance can be stopped any time during any of the above operation by pressing the ON/OFF key.

Care and Cleaning

1. Always disconnect the appliance from the electrical outlet before cleaning.
2. Never immerse the appliance, power cord and plug into water or allow moisture to come in contact with the appliance.
3. Wipe the exterior parts of the appliance with a mild and damp cloth or cleaner. Never use a corrosive cleaner.
4. For proper storage, always place the appliance in a low humidity environment.



Marketed by:

CORNELL SALES & SERVICE SDN BHD (604369-P)

Lot 11B, Jalan 223, Section 51A,
46100 Petaling Jaya,
Selangor Darul Ehsan, Malaysia.

InfoLine: 1-800-881-770
www.cornellappliances.com